

1. SAFETY RULES

- This meter is designed for indoor use at temperatures between 0°C to 40°C and altitudes up to 2,000m.
- To ensure that the meter is used safely, follow all safety and operating instructions in this operation manual. If the meter is not used as described in this operation manual, the safety features of this meter might be impaired.
- Do not use the meter if the meter or test leads look damaged ,or if you suspect that the meter is not operating properly.
- When using the instrument, keep your fingers behind the finger guards on the plastic casing and probes.
- Disconnect the live test lead before disconnecting the common test lead.
- Make sure power is off before cutting, desoldering, or breaking the circuit wires. Small amounts of current can be dangerous.
- Do not apply more than 600 VDC or 600V AC rms between a terminal and ground.
- To avoid electrical shock, use CAUTION when working above 60V DC or 25V AC rms. Such voltages pose a shock hazard.
- Never make measurements with the battery cover off.
- To avoid electrical shock or damage to the meter, do not exceed the input limits.

2. INTERNATIONAL SYMBOLS

	Important information see manual		Dangerous Voltages
	AC		Continuity
	DC		Ground
			Double Insulation

3. TECHNICAL SPECIFICATIONS

3.1 General Specifications

Display:	3-1/2 digits LCD, max. of 1999 display
Polarity:	Automatic, (-) negative polarity indication
Zero adjustment:	Automatic
Sample rate:	0.5 Sec.
Over range indication:	Only the MSD "1" is displayed
Power:	9-volt battery type NEDA 1604, IEC6F22
Battery life:	Approx. 50 hours. (w/ alkaline batteries)
Dimension:	141 x 69 x 36 mm.
Weight:	Approx. 330g (including battery).
Accessories:	User's Manual, Test Leads, Protective Holster, Soft Pouch and 9V battery

3.2 Electrical Specifications


- Accuracies are \pm (% of reading + number of least significant digits) at 23°C \pm 5°C, less than 75% RH.

Function	Range	Accuracy	Input Impedance	Remarks	Overload Protection
DC Voltage	200mV, 2000mV, 20V, 200V, 600V	0.8%+1	1 M Ω	-	600 Vp-p
AC Voltage	200V, 600V	1.5%+10	450 K Ω	40~400Hz	600 Vp-p
DC Current	200 μ A, 2000 μ A, 20mA	1.0%+2	-	-	200 mA - 250V Fuse
	200mA	1.2%+2	-	-	
	10A	2.0%+5			10 A - 250V Fuse
Resistance	200 Ω , 2K Ω , 20k Ω , 200k Ω	1.0%+3	-	-	250 Vp-p
	2000k Ω	1.0%+3			250 Vp-p
Continuity	Buzzer sounds when <100 Ω		Test Voltage: 2.4 V Max.		250 Vrms
Diode Test	Test Current:1.0 \pm 0.6mA		Test Voltage: 2.4 V Max.		250 Vrms
Transistor Test	NPN and PNP Compatible		0 to 1000hFE		-

4. OPERATION

4.1 Instrument Description

- Case
- 3-1/2 Digit LCD display
- DC Voltage range
- Function/Range switch
- DC Current range
- Input Sockets
- Power OFF
- AC Voltage range
- Transistor Test
- Resistance range
- Diode Continuity Test
- Transistor Test Socket



4.2 Measurement Procedures

CAUTION: Maximum Input Voltage is 600Vrms, do not exceed this rating to avoid personal injuries or damage to the instrument. The range FUNCTION/RANGE switch should be set to the range you want to test before the operation.

CAUTION: Always ensure that the correct terminals are used for the type of measurement to be made. Avoid making connections to "live" circuits whenever possible. When making current measurements ensure that the circuit is not "live" before opening it in order to connect the test leads.

4.2.1 DC Voltage measurement

- Connect the black test lead to the "COM" socket and red test lead to the "V Ω mA" socket.
- Set the **FUNCTION/RANGE** switch to the desired range in the "V \sim " function. If the voltage range is not known beforehand, set the switch to the highest range and work down as needed.
- Connect the test leads across the source or load under measurement.
- The measurement and polarity will be shown the LCD Display when the probe are connected.


4.2.2 AC Voltage measurement

- Connect the black test lead to the "COM" socket and red test lead to the "V Ω mA" socket.
- Set the **FUNCTION/RANGE** switch to the desired range in the "V \sim " function. If the voltage range is not known beforehand, set the switch to the highest range and work down as needed.
- Connect the test leads across the source or load under measurement.
- The measurement will be shown the LCD Display when the probe are connected.

4.2.3 DC Current measurement

- Connect the black test lead to the “**COM**” socket and red test lead to the “**V Ω mA**” socket for below 200mA currents. For measurements between 200mA and 10 A, the red test lead should be connected to the **10A** socket.
- Set the **FUNCTION/RANGE** switch to the desired range in the “**A \rightarrow** ” function. If the current range is not known beforehand, set the switch to the highest range and work down as needed.
- Connect the test leads in series with the source or load under measurement.
- The measurement and polarity of the current will be shown the LCD Display when the current is flowing through the instrument.


4.2.4 Resistance measurement


 **CAUTION:** Maximum Input Voltage for this function is 250 Vrms for less than 10 Sec., do not exceed this rating to avoid personal injuries or damage to the instrument. Also ensure there is no power applied to the component or circuit and all capacitors are discharged.

- Connect the black test lead to the “**COM**” socket and red test lead to the “**V Ω mA**” socket.
- Set the **FUNCTION/RANGE** switch to the desired range in the “ **Ω** ” function. If the resistance range is not known beforehand, set the switch to the highest range and work down as needed.
- Connect the test leads across the component or circuit under measurement.
- The measurement will be shown the LCD Display when the probe are connected.


4.3 Other Functions


4.3.1 Diode test

 **CAUTION:** Maximum Input Voltage for this function is 250 Vrms for less than 10 Sec., do not exceed this rating to avoid personal injuries or damage to the instrument. Also ensure there is no power applied to the diode.

- Connect the black test lead to the “**COM**” socket and red test lead to the “**V Ω mA**” socket.
- Set the **FUNCTION/RANGE** switch to the  function.
- Proceed to connect the test leads across the diode observing the polarity: red probe to the anode (+) of the diode and black test lead to the cathode (-).
- The measurement will be shown the LCD Display when the diode is connected.

4.3.2 Continuity Test


 **CAUTION:** Maximum Input Voltage for this function is 250 Vrms for less than 10 Sec., do not exceed this rating to avoid personal injuries or damage to the instrument. Also ensure there is no power applied to the circuit.

- Connect the black test lead to the “**COM**” socket and red test lead to the “**V Ω mA**” socket.
- Set the **FUNCTION/RANGE** switch to the  function.
- Proceed to connect the test leads across the circuit.
- Buzzer will sound if the circuit resistance is below 100 Ω .

4.3.2 Transistor Test

Set the selector switch to “**hFE**” position, proceed to insert the transistor leads into the socket, observing to the type of transistor (NPN or PNP) and pinout. Read hFE on the LCD display.

5. MAINTENANCE

 **CAUTION:** Before attempting battery removal or replacement, disconnect test leads and remove the instrument from any energized circuit to avoid shock hazard.

5.1 Battery Replacement

- To replace the battery, remove the screw of the back **Battery Cover** (back of the case) and remove the battery.
- Replace with a new 9 V alkaline battery type NEDA 1604 or IEC6F22 observing the proper polarity from the diagram on the label inside the battery compartment.
- Reinstall the battery cover and tighten the securing screw.

5.2 Fuse replacement

- Remove the screw of the back **Battery Cover** (back of the case) and remove the battery.
- Remove the screws at the bottom of the case and of the battery compartment.
- Replace new fuses only with the identical type and rating.

F1=200mA: Type IEC60127-2 or UL248-14 (5 x 20mm)
fast acting fuse, rated at 200mA/250V.

F2=10A: Type IEC60127-2 or UL248-14 (6.3x25.4mm)
fast acting fuse, rated at 10A/250V.

- Reinstall the back cover, and replace the four screws,
- Reinstall the battery observing the polarity on the battery compartment label, the battery cover and tighten the securing screw.

5.3 Cleaning

Periodically wipe the case with a soft damp cloth and mild household cleanser. Do not use abrasives or solvents. Ensure that no water gets inside the instrument to prevent possible shorts and damage.

6. WARRANTY

One year limited warranty, excluding batteries and fuses. For details see Standard Warranty Information in our webpage or you may request a printed copy.

General Technologies Corp.

#121 - 7350 72nd Street	Tel.: (604) 952-6699
Delta, BC V4G 1H9	Fax: (604) 952-6690
Canada	www.gtc.ca